



MOTOROLA

Motorola Bluetooth™ Headset

Dimensions:

A tiny powerhouse, the Bluetooth Headset is smaller than two inches in diameter & weighs less than an ounce.

Talk & Stand by:

The headset features up to 2.5 hours talk and 10 hours stand-by time, storage time (boom closed) 20 days.

Range:

Up to 33-feet (10 Meters)

Additional:

Can be configured to wear on the left or right ear

Compatibility:

The headset is compatible with Bluetooth enabled mobile phones and audio devices from Motorola and other vendors. The Bluetooth sw version for the headset is 1.1. Bluetooth modules that house 1.0 sw will work with the headset, however, when linked for the 1st time, they will receive an error message. To bypass this, pwr off the phone, and then pwr it on. When the unit relinks to the headset, bonding will occur.



Part numbers:

Retail: 98405H (includes charger SPN4940C, Lanyard SYN9490A, Holster SYN9484A, and manual SJJN4500A). Bulk: SYN9006A
Compatibility: Motorola T270, T280i - both require BT clip-in module accessories, other BT 1.1 compatible phones and devices.


What is the Bluetooth Headset?

The new Bluetooth Headset by Motorola offers users a unique, wireless experience using the revolutionary Bluetooth wireless technology. Combining Motorola's expertise in wireless connectivity and GN NetCom's proficiency in headset ergonomics and acoustics, the new Bluetooth Headset provides very high quality hands-free, wireless headset-to-headset compatibility. It is a model of efficiency, offering hands-free, wireless connections between most phones that utilize Bluetooth wireless technology.

Whether on the road or in the office, the Bluetooth Headset is your key to connecting to a wide variety of devices without cable attachments. Gone are the days of carrying bulky cords and trying to find a place to plug them in. Bluetooth connections are virtually instantaneous and do not require devices to be within line of sight.

The headset's compact over-the-ear (OTE) style adds convenience and comfort. The new Bluetooth Headset by Motorola offers supreme versatility with the capability to be worn over either ear while the volume control remains in an upward position, making it easy to locate.

Navigation:



- 1—**Headset Indicator light** Provides visual cue about headset status.
- 2—**Volume Control** Adjusts speaker (receive) volume up and down.
- 3—**Microphone** Picks up your voice input.
- 4—**Boom** Contains microphone and controls power (On/Off) status of headset.
- 5—**Earhook** Attaches headset to ear.
- 6—**Speaker** Plays the sound you receive on the call.
- 7—**Charging Port** Receives the plug for your battery charger.
- 8—**Lanyard Loop** Lets you attach a lanyard to the headset, so you can wear the headset around your neck and always keep it near.
- 9—**Multifunction Button** Controls several headset functions.

Charging:

The battery in this headset is self contained, and can be charged by a standard P2K charger. For optimal use, charge battery for 2 hours. When the battery requires recharging,, five rapid high tones will be heard through the headset speaker, and repeated at 20 second intervals.

How to Charge

Step

- 1 Plug the Motorola charger into the headset, with the charger's release tab and the headset both facing up.
- 2 Plug the other end of the charger into an electrical outlet. During charging, the headset indicator turns on and remains lit until charging is complete. Your headset requires approximately two hours to receive a full charge.
- 3 When charging is complete (indicator is off), remove the charger from the electrical outlet, press the release tab, and detach the charger cord from the headset.


Wearing the Headset

Placing the Headset on Your Ear

When packaged, the headset is configured for wear on the right ear.

Step

- 1 Open the boom, then open the earhook (90° from the headset).
- 2 Loop the earhook over your ear.
- 3 Press the headset to your ear.
- 4 Point the boom toward your mouth.




Changing for Wear on the Left Ear

When packaged, the headset is configured for wear on the right ear. To change it for wear on your left ear:

Step

- 1 Open the boom, then open the earhook (90° from the headset).



- 2 Gently lift and pull the top of the earhook up and off the upper hinge pin. Then pull it away to remove it.



- 3 Flip the headset over.


- 4 Hook the bottom of the earhook onto the lower hinge pin, then lift and pull the top of the earhook over the upper hinge pin.

Linking Your Headset & Phone:

You must link your headset and phone before you can make a call.

Once you have accomplished this task, you have established a paired link. A paired link means that your phone will remember your headset ID, and will automatically connect to your headset when the boom mic is opened.

With the headset and phone in close proximity:

Step	Result
1 With the headset's boom closed, press and hold the Multifunction Button  for two seconds.	The headset indicator turns on.
2 Open the headset boom.	The indicator remains lit.
3 Perform a <i>device discovery</i> from the phone. For Motorola phones, perform device discovery by selecting these options: Settings > Connection > Bluetooth Link > Hands Free > Scan All <i>For details on device discovery for another phone, refer to the user's guide for the phone.</i>	When the scan is complete, the phone displays: Bond with Motorola headset
4 Press the YES soft key on the phone to bond to the headset.	It may take several seconds to establish a connection.
5 When Enter Bluetooth Passkey appears, enter the passkey 0000, then press OK on the phone to pair the headset with the phone.	The device ID is now stored in the phone's memory. Pairing is successful when the headset indicator flashes 10 times rapidly.
6 Press the Link soft key on the phone.	The audio gateway is established between your phone and headset.
7 Press the END key on the phone to exit the Bluetooth menu	The phone returns to idle. You can now place and receive calls. (See "Placing a Call" on page 18 and "Receiving a Call" on page 20.)

Troubleshooting Tips

Placing a call:

- 1st Link your headset to the phone!
- From Phone Keypad:
- Dial the # via the phone keypad
- Press SND from phone or press the headset multifunction button

Voicedial:

- Press the Multifunction key
- Say the voice tag name (a tone sound will prompt you to speak the name for the person you wish to call, as entered in the Phonebook).

Redial:

- Turn Voicedial feature off
- Press the Multifunction key to recall the last number dialed
- Press Multifunction key again to send the call

Ending a Call:

- Press the Multifunction key (a tone will emit when the call disconnects).

Receive a Call with Headset On & Links

- A tone will sound in your headset (if boom is open & links)
- To answer press the Multifunction key

How do I switch from phone to HS?

- Open the boom to activate the auto-transfer feature
- If the boom is open & the call is on the phone, press the Multifunction key